




Acer Aspire V5-572, V5-572G HDD Replacement

Acer Aspire V5-572, V5-572G HDD Replacement

Written By: ZFix



INTRODUCTION

Acer Aspire - V5-572, V5-572G

Follow this guide if you want to change / upgrade your HDD (Hard Disk Drive) or install SSD (Solid State Drive).

[Please SUBSCRIBE to my channel ツ](#)

[video: <https://www.youtube.com/watch?v=Sg8tUXZL864>]



TOOLS:


- [Phillips #0 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [iFixit Opening Picks set of 6](#) (1)



PARTS:


- [500 GB 5400 RPM 2.5" Hard Drive](#) (1)
- [1000 GB 5400 RPM SATA Hard Drive](#) (1)
- [1 TB SSD Hybrid 2.5" Hard Drive](#) (1)
- [500 GB SSD Hybrid 2.5" Hard Drive](#) (1)

Step 1 — Bottom Cover




- Switch-off the Laptop.
- Remove 17x Philips screws.

Step 2



- Start opening from the SD Memory Card hole
- ⚠ Use plastic tools to avoid damaging the cover.



Step 3



⚠ Before doing anything, disconnect the battery.

★ [Please SUBSCRIBE to my channel](#)
ツ

Step 4 — HDD



- Disconnect the SATA Cable from the Mother Board.
- Take out the HDD and remove the SATA cable from it.
- Now you can change / upgrade your HDD.

★ [Please SUBSCRIBE to my channel](#) ツ

To reassemble your device, follow these instructions in reverse order.

